



FURNISH ALL TUBE OR PIPE SUPPORTS WITH A CAP. USE EITHER GALVANIZED STEEL OR A CAST ALUMINUM CAP TO MATCH THE MATERIAL OF THE POLE. USE FOUR SET SCREWS FOR ATTACHMENT TO SUPPORT.

